


1. Открываем любой браузер (Internet Explorer, Mozilla FireFox, Google Chrome, Opera и др.).
2. В адресной строке необходимо набрать 192.168.0.1 (web-интерфейс модема):



3. Попадаем на страницу авторизации.  
Username (имя пользователя): **home**  
Password (пароль): **home**  
Нажимаем: **LOGIN**

LOGIN

Username:

Password:

**LOGIN**

4. Выбираем **ADVANCED SETTINGS**

**YOUR WIRELESS NETWORK**

Here you can change the network name and set the password of your choice.

2.4 GHz wireless network has the longest range

5 GHz wireless network has the highest speed:

Password:

Display the security key

Enter your own if you do not want to use the default password

**SAVE**

**ADVANCED SETTINGS**

#### 4. Переходим Wireless → WiFi Setup

The screenshot shows the Sagemcom router's configuration interface. The 'Wireless' tab is active. The page is split into two columns for 2.4GHz and 5GHz Wi-Fi settings. In the 2.4GHz column, the Wi-Fi mode is 802.11 b/g/n, bandwidth is 20MHz, and channel selection is set to Auto (Current: 1). In the 5GHz column, the Wi-Fi mode is 802.11AC, bandwidth is 80MHz, and channel selection is set to Auto (Current: 52/80). Both columns have 'Enable W-Fi Network' and 'Enable SSID Broadcasting' checked. Security options are set to WPA2-PSK [AES] with a key field. At the bottom, there are 'Apply' and 'Cancel' buttons.

Столбец **WI-FI 2.4G** – персональные настройки 2.4Ghz;

Столбец **WI-FI 5G** – персональные настройки сети 5Ghz;

**Channel selection** – Частотный канал wi-fi.

Для сохранения параметров , необходимо нажать **APPLY**